

## INSTRUCTIONS

### How to Use:

Write a note, then shine the light in the pen lid to reveal the secret message!

### WARNING!



Contains Non-replaceable Button Batteries. Button batteries are hazardous and can cause serious injuries if swallowed or placed inside any part of the body.

Do not attempt to access the batteries – Once they have expired, please dispose of the pen in your domestic rubbish. It is not suitable for recycling.

Keep button batteries away from children whether new or used. If you think that button batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. In Australia, call the 24-hour Poisons Information Centre on 13 11 26 for fast, expert advice.

Please keep these instructions for future reference